

S&S

OFFICE INTERIORS LTD

OFFICE FIT OUT - FURNITURE - PARTITIONING
SHOWROOM

pepi

USER INSTRUCTIONS



1. Height adjustable ratchet back

Adjust back via integral ratchet system. Lift the whole of the back and raise to desired position (six clicks to highest position).

To reduce height, lift back to its highest level, and the back will return to its lowest position.

2. Height Adjustable Arms

Press button on the outside of the arm and lift to the desirable height. Release button to lock in place.

3. Tension

Pull out the lever and turn clockwise to increase the tension, to compensate for body weight, and turn anti-clockwise to decrease.

4. Seat Height

Lift paddle to raise the seat. Lift lever and apply weight to lower the seat.

5. Lumbar Support (optional)

Squeeze the bulb repeatedly under the seat to pump up the lumbar pillow in the backrest to give additional lower back support. Press button to deflate.

6. Back/Seat lock

Turn lever clockwise to release the back and seat and anti-clockwise to lock both seat and back in desired angle. We suggest to leave the mechanism unlocked, in free float mode, to encourage more body movement.

7. Seat Slide (optional)

Lift paddle and slide seat backwards or forwards to desired position.