

S & S

OFFICE INTERIORS LTD

OFFICE FIT OUT - FURNITURE - PARTITIONING
SHOWROOM

Axia Air

User Instructions





1a: Static seat angle

Raise the lever. Tilt the seat back to the desired angle. Depress the lever to lock into position.



1b: Dynamic seat angle

Raise the lever. The seat angle can now be adjusted freely backwards and forwards.



2: Seat height

Raise the lever. Adjust the seat to the required height. Release the lever to lock into position. The seat should now provide even support for the thighs.



3: Seat depth

Pull out the sliders on either side of the chair. Slide the seat forwards or backwards to select the required depth. The correct seat depth allows a hands breadth between the seat and the back of your knee.



4: Pelvic Support

The pelvic support can be height adjusted on either side of the backrest. Make sure both sides are set to the same height and that the lumbar support provided is comfortable.



5: Backrest angle

Raise the lever. Using your upper body, tilt the backrest backwards completely. Sit back as far as possible. Lift the lever again, allowing the backrest to tilt forward, until the pressure on the lower back is optimal.



6: Armrest height

Depress the buttons on the armrests to adjust them to the height required for supporting your forearms when working. Release the button to lock into position. Adjust the armrests separately from the current height of your desktop.

7: Height of desktop

Adjust the height of the desktop or keyboard to the same height as the top of the armrests.



8: Weight setting

You are sitting in balance when the chair follows you in every position without having to apply force. Rotate the knob to find the required point of equilibrium.